

Canebrake County Water Board

POST-operation check list

CAT 303-5 Mini Excavator

CAT 239D Track Steer

Project completion - equipment shut down

-
- Prior to leaving project make sure roads and washes are groomed. Minimize track prints.
 - Shut off and exit vehicle in open area near garage.
 - Walk entire vehicle for leak inspection - report any unusual leaks or fluid loss to Equipment MGR.
 - Add fuel so vehicle is prepared for next project.
 - Hose down vehicle and rinse off any sand or material especially in the rubber track mechanisms and bucket ares. DO NOT USE water to squirt rear radiator. Blow with air only.
 - Wipe down vehicles and clean windshield on track steer.
 - Wipe down interior for dust removal
 - Lock windows on track steer
 - Start and move vehicles to storage garage (track steer nose first then back in Excavator).
 - Make sure all buckets and blades are dropped to the ground prior to shutdown.
 - Close and secure door on Track steer.
 - Remove any personal items and materials such as jackets, drink containers from vehicles.
 - Remove keys from switch. Place keys in supply shed or preferably in office desk.
 - Attach battery maintainers to each tractor. (Excavator will require ignition key access to battery door).
 - Make sure battery maintainers are lit with red light.
 - Use WD40 on bucket attachment areas after use.
 - Log and report dates and hours of use and the project name to Ron Akey or Equipment Manager.

Thank you all for keeping our equipment maintained and looking professional

SAFETY SAFETY SAFETY!