

Canebrake County Water Board

Pre-operation check list

CAT 303-5 Mini Excavator

CAT 239D Track Steer

Prior to start -up: Inform CCWD Equipment Mgr or President of project and intended use

- Unhook battery maintainer cord and clip from battery
- Walk entire vehicle for leak inspection - report any unusual leaks or fluid loss to Equipment MGR.
- Open engine doors - check air filters - blow out if necessary.
- Check hydraulic fluid levels
- Check oil levels
- Observe coolant tanks and levels
- Clean windshield

Start-up

- Check surrounding area for any obstacles
- Check fuel level gauges - Add #2 Diesel if needed (no Bio Diesel)
- Attach Seat belt
- Start engine - wait for warm up time (1-2 minutes)
- Throttle up - back out equipment to and open area for further pre-operation maintenance
- Shut off - exit vehicle
- Use cordless grease gun - Grease all ZERK fittings based on ZERK location map posted on vehicles
- Use WD40 on bucket attachment areas
- Check rubber tracks for wear and looseness. Add grease if needed.

You are good to Go!

Always have a spotter! SAFETY SAFETY SAFETY!